


Operating Instructions



The MIS-07 was designed for the armored vehicle industry to allow the driver to communicate with a person outside, without opening a window. As well as an intercom, the MIS-07 also includes a Public Address System and a Siren.

The system consists of a main intercom unit which is mounted under the dash board, a paging horn mounted under the hood, and a small microphone which is mounted in the outside rear view mirror on the driver's side. It includes a hand held microphone with push to talk switch which hangs on a clip mounted on the dash. Once installed and connected to the vehicle's 12 volt electrical system, it is ready to use.

To operate the system, simply turn on the power switch. A green LED illuminates to indicate that it is functioning. Adjust the Left Hand volume control (Outside Mic) to obtain the desired volume from the outside microphone. You will hear this through a speaker built into the main unit.

In order to speak to people outside the vehicle, press the talk switch on the hand held microphone and adjust the second volume control (Inside Mic) to the desired level. When you press the talk switch, the internal speaker is muted, so you won't hear your own voice coming back through the outside microphone. You should experiment with this volume level with the window or door open so you can hear it. Once you have determined the level you want, you will probably not need to adjust it again.

To operate the siren, turn on the siren switch on the right side of the unit. There is no external volume control for the siren. It is preset internally. The centre switch selects Yelp or Wail for the siren.

For more information, visit www.alectro.ca
or contact:

Alectro Systems Inc.
2861 Sherwood Hts. Dr. Unit 24
Oakville, ON L6J 7K1 Canada

Phone: 905-829-1117, Toll Free 1-866-308-2616